

ATmega32U4	Arduino Leonardo
(#HWB) PE2	HWB (BOOT BTN)
(INT.6/AIN0) PE6	Digital pin 7
(SS/PCINT0) PB0	RXLED
(PCINT1/SCLK) PB1	SCK
(PDI/PCINT2/MOSI) PB2	MOSI
(PDO/PCINT3/MISO) PB3	MISO
(ADC11/PCINT4) PB4	Digital pin 8
(PCINT5/OC1A/#OC4B/ADC12) PB5	Digital Pin 9 (PWM)
(PCINT6/OC1B/OC4B/ADC13) PB6	Digital Pin 10 (PWM)
(PCINT7/OCA0/OC1C/#RTS) PB7	Digital pin 11 (PWM) (LED)
(OC3A/#OC4A) PC6	Digital Pin 5 (PWM)
(ICP3/CLK0/OC4A) PC7	Digital Pin 13
(OC0B/SCL/INT0) PD0	Digital pin 3 (SCL)(PWM)
(SDA/INT1) PD1	Digital pin 2 (SDA)
(RXD1/AIN1/INT2) PD2	Digital pin 0 (RX)
(TXD1/INT3) PD3	Digital pin 1 (TX)
(ICP1/ADC8) PD4	Digital pin 4
(XCK1/#CTS) PD5	TXLED
(T1/#OC4D/ADC9) PD6	Digital pin 12
(T0/OC4D/ADC10) PD7	Digital Pin 6 (PWM)
(ADC0) PF0	
(ADC1) PF1	
(ADC4/TCK) PF4	Analog In 3
(ADC5/TMS) PF5	Analog In 2
(ADC6/TDO) PF6	Analog In 1
(ADC7/TDI) PF7	Analog In 0